

Valve Size	Required Actuator Range	Actuator Torque (Actual torque, no additional safety factor included)				Individual Part Order Code* (If ordered with the below order codes, Easytork will ship each part as standalone)				List Price					Complete Actuator to Valve Order Code*
		DA @ 60PSI	DA @ 80PSI	FS @ 60PSI	FS @ 80PSI	Actuator	Insert	Extended Shaft	Bracket	Actuator +	Insert +	Extended Shaft +	Bracket or Plate +	= Total Package: Actuator and hardware for mounting to valve	
1 1/2"	EVA-0411	288	384	187	250	C-A-2-11-1-111	D-212-0.625x0.372in	K-AS-2-1-1-2	B-2-F07M-F04M-1.79in						
	EVA-0514	572	763	372	496	C-A-3-11-1-111	D-312-0.625x0.372in	K-AS-3-1-1-2	B-2-F07M-F05M-2.29in						
2"	EVA-0411	288	384	187	250	C-A-2-11-1-111	D-212-0.625x0.372in	K-AS-2-1-1-2	B-2-F07M-F04M-1.79in						
	EVA-0514	572	763	372	496	C-A-3-11-1-111	D-312-0.625x0.372in	K-AS-3-1-1-2	B-2-F07M-F05M-2.29in						

Easytork will ship the actuator, insert, extended shaft, and bracket unassembled in one SKU box.

Refer to [Assembly & Labor tab](#) if buyer wants Easytork to assemble items together.

AP.86R-700.1 1/2".0411.16
 AP.86R-700.1 1/2".0514.16
 AP.86R-700.2".0411.16
 AP.86R-700.2".0514.16

Disclaimer: Based on information available from valve manufacturer. All dimensions to be verified by customer prior to purchase confirmation.

Note*: Only for actuator and hardware required for mounting to valve. Order auxiliary add-ons (e.g., solenoid valve, lockout & PST, limit switch, chemical resistant adder, etc.) separately. If buyer requires assembly of auxiliary add-ons and/or valve, labor will be charged separately.