

Valve Size	Required Actuator Range	Individual Part Order Code* (If ordered with the below order codes, Easytork will ship each part as standalone)				2017 List Price					Complete Actuator to Valve Order Code*
		Actuator	Insert	Extended Shaft	Bracket	Actuator +	Insert +	Extended Shaft +	Bracket or Plate +	= Total Package: Actuator and hardware for mounting to valve	
1/4"	EVA-0309	C-A-1-11-1-111									AT.33/43/53.1/4".0309.16
	EVA-0411	C-A-2-11-1-111	D-211-0.350x0.350in								AT.33/43/53.1/4".0411.16
3/8"	EVA-0309	C-A-1-11-1-111									AT.33/43/53.3/8".0309.16
	EVA-0411	C-A-2-11-1-111	D-211-0.350x0.350in								AT.33/43/53.3/8".0411.16
1/2"	EVA-0309	C-A-1-11-1-111									AT.33/43/53.1/2".0309.16
	EVA-0411	C-A-2-11-1-111	D-211-0.350x0.350in								AT.33/43/53.1/2".0411.16
3/4"	EVA-0411	C-A-2-11-1-111									AT.33/43/53.3/4".0411.16
	EVA-0514	C-A-3-11-1-111	D-311-0.430x0.430in								AT.33/43/53.3/4".0514.16
1"	EVA-0514	C-A-3-11-1-111	D-311-0.430x0.430in								AT.33/43/53.1".0514.16
	EVA-0717	C-A-4-11-1-111	D-411-0.430x0.430in								AT.33/43/53.1".0717.16
1 1/4"	EVA-0514	C-A-3-11-1-111									AT.33/43/53.1 1/4".0514.16
	EVA-0717	C-A-4-11-1-111	D-411-0.550x0.550in								AT.33/43/53.1 1/4".0717.16
1 1/2"	EVA-0717	C-A-4-11-1-111	D-411-0.748x0.748in								AT.33/43/53.1 1/2".0717.16
	EVA-1022	C-A-5-11-1-111	D-511-0.748x0.748in								AT.33/43/53.1 1/2".1022.16
2"	EVA-0717	C-A-4-11-1-111	D-411-0.748x0.748in								AT.33/43/53.2".0717.16
	EVA-1022	C-A-5-11-1-111	D-511-0.748x0.748in								AT.33/43/53.2".1022.16
2 1/2"	EVA-1022	C-A-5-11-1-111	D-511-0.748x0.748in								AT.33/43/53.2 1/2".1022.16
	EVA-1227	C-A-6-11-1-111	D-611-0.748x0.748in								AT.33/43/53.2 1/2".1227.16
3"	EVA-1022	C-A-5-11-1-111									AT.33/43/53.3".1022.16
	EVA-1227	C-A-6-11-1-111	D-611-0.870x0.870in								AT.33/43/53.3".1227.16
4"	EVA-1227	C-A-6-11-1-111	D-611-0.870x0.870in								AT.33/43/53.4".1227.16
	EVA-1436	C-A-7-11-1-111	D-711-0.870x0.870in								AT.33/43/53.4".1436.16

Easytork will ship the actuator, insert, extended shaft, and bracket unassembled in one SKU box.

Refer to [Assembly & Labor tab](#) if buyer wants Easytork to assemble items together.

Disclaimer: Based on information available from valve manufacturer. All dimensions to be verified by customer prior to purchase confirmation.

Note*: Only for actuator and hardware required for mounting to valve. Order auxiliary add-ons (e.g., solenoid valve, lockout & PST, limit switch, chemical resistant adder, etc.) separately. If buyer requires assembly of auxiliary add-ons and/or valve, labor will be charged separately.