

Valve Size	Required Actuator Range	Individual Part Order Code* (If ordered with the below order codes, Easytork will ship each part as standalone)				2017 List Price				Complete Actuator to Valve Order Code*	
		Actuator	Insert	Extended Shaft	Bracket	Actuator +	Insert +	Extended Shaft +	Bracket or Plate +		= Total Package: Actuator and hardware for mounting to valve
1/4"	EVA-0309	C-A-1-11-1-111		K-AS-1-1-1-2	B-2-F04S-F04S-1.23in						AT.38.1/4".0309.16.N
	EVA-0309	C-A-1-11-1-111		K-AS-1-1-1-2	B-2-F04S-F04S-1.23in						AT.38.1/4".0309.16.N
3/8"	EVA-0309	C-A-1-11-1-111		K-AS-1-1-1-2	B-2-F04S-F04S-1.23in						AT.38.3/8".0309.16.N
	EVA-0309	C-A-1-11-1-111		K-AS-1-1-1-2	B-2-F04S-F04S-1.23in						AT.38.3/8".0309.16.N
1/2"	EVA-0309	C-A-1-11-1-111		K-AS-1-1-1-2	B-2-F04S-F04S-1.24in						AT.38.1/2".0309.16.N
	EVA-0411	C-A-2-11-1-111	D-211-0.350x0.350in	K-AS-2-1-1-2	B-2-F04S-F04S-1.24in						AT.38.1/2".0411.16.N
3/4"	EVA-0411	C-A-2-11-1-111		K-AS-2-1-1-2	B-2-F05S-F04S-1.29in						AT.38.3/4".0411.16.N
	EVA-0411	C-A-2-11-1-111		K-AS-2-1-1-2	B-2-F05S-F04S-1.29in						AT.38.3/4".0411.16.N
1"	EVA-0411	C-A-2-11-1-111		K-AS-2-1-1-2	B-2-F05S-F04S-1.37in						AT.38.1".0411.16.N
	EVA-0514	C-A-3-11-1-111	D-311-0.430x0.430in	K-AS-3-1-1-2	B-2-F05S-F05S-1.87in						AT.38.1".0514.16.N
1 1/4"	EVA-0411	C-A-2-11-1-111		K-AS-2-1-1-2	B-2-F05S-F04S-1.34in						AT.38.1 1/4".0411.16.N
	EVA-0514	C-A-3-11-1-111	D-311-0.430x0.430in	K-AS-3-1-1-2	B-2-F05S-F05S-1.84in						AT.38.1 1/4".0514.16.N
1 1/2"	EVA-0514	C-A-3-11-1-111	D-311-0.430x0.430in	K-AS-3-1-1-2	B-2-F07M-F05M-1.97in						AT.38.1 1/2".0514.16.N
	EVA-0717	C-A-4-11-1-111	D-411-0.430x0.430in	K-AS-4-1-1-2	B-2-F07M-F07M-1.97in						AT.38.1 1/2".0717.16.N
2"	EVA-0514	C-A-3-11-1-111		K-AS-3-1-1-2	B-2-F07M-F05M-1.95in						AT.38.2".0514.16.N
	EVA-0717	C-A-4-11-1-111	D-411-0.550x0.550in	K-AS-4-1-1-2	B-2-F07M-F07M-1.95in						AT.38.2".0717.16.N

Easytork will ship the actuator, insert, extended shaft, and bracket unassembled in one SKU box.

Refer to [Assembly & Labor tab](#) if buyer wants Easytork to assemble items together.

Disclaimer: Based on information available from valve manufacturer. All dimensions to be verified by customer prior to purchase confirmation.

Note*: Only for actuator and hardware required for mounting to valve. Order auxiliary add-ons (e.g., solenoid valve, lockout & PST, limit switch, chemical resistant adder, etc.) separately. If buyer requires assembly of auxiliary add-ons and/or valve, labor will be charged separately.