

Valve Size	Required Actuator Range	Individual Part Order Code*				List Price					Complete Actuator to Valve Order Code*
		(If ordered with the below order codes, Easytork will ship each part as standalone)				Actuator +	Insert +	Extended Shaft +	Bracket or Plate +	= Total Package: Actuator and hardware for mounting to valve	
		Actuator	Insert	Extended Shaft	Bracket						
1/4"	EVA-0309	C-A-1-11-1-111	Use Apollo Hardware, actuator has 9mm sq stem								AP.86A-200.1/4".0309.16
	EVA-0309	C-A-1-11-1-111									AP.86A-200.1/4".0309.16
3/8"	EVA-0309	C-A-1-11-1-111	Use Apollo Hardware, actuator has 9mm sq stem								AP.86A-200.3/8".0309.16
	EVA-0309	C-A-1-11-1-111									AP.86A-200.3/8".0309.16
1/2"	EVA-0309	C-A-1-11-1-111	Use Apollo Hardware, actuator has 9mm sq stem								AP.86A-200.1/2".0309.16
	EVA-0309	C-A-1-11-1-111									AP.86A-200.1/2".0309.16
3/4"	EVA-0309	C-A-1-11-1-111	Use Apollo Hardware, actuator has 9mm sq stem								AP.86A-200.3/4".0309.16
	EVA-0411	C-A-2-11-1-111									AP.86A-200.3/4".0411.16
1"	EVA-0411	C-A-2-11-1-111	Use Apollo Hardware, actuator has 11mm sq stem								AP.86A-200.1".0411.16
	EVA-0514	C-A-3-11-1-111									AP.86A-200.1".0514.16
1 1/4"	EVA-0514	C-A-3-11-1-111	D-312-0.625x0.412in	K-AS-3-1-1-2	#VALUE!						AP.86A-200.1 1/4".0514.16
	EVA-0717	C-A-4-11-1-111	D-412-0.625x0.412in	K-AS-4-1-1-2	#VALUE!						AP.86A-200.1 1/4".0717.16
1 1/2"	EVA-0514	C-A-3-11-1-111	D-312-0.625x0.412in	K-AS-3-1-1-2	#VALUE!						AP.86A-200.1 1/2".0514.16
	EVA-0717	C-A-4-11-1-111	D-412-0.625x0.412in	K-AS-4-1-1-2	#VALUE!						AP.86A-200.1 1/2".0717.16
2"	EVA-0514	C-A-3-11-1-111	D-312-0.750x0.477in	K-AS-3-1-1-2	#VALUE!						AP.86A-200.2".0514.16
	EVA-0717	C-A-4-11-1-111	D-412-0.750x0.477in	K-AS-4-1-1-2	#VALUE!						AP.86A-200.2".0717.16

Easytork will ship the actuator, insert, extended shaft, and bracket unassembled in one SKU box.

Refer to [Assembly & Labor tab](#) if buyer wants Easytork to assemble items together.

Disclaimer: Based on information available from valve manufacturer. All dimensions to be verified by customer prior to purchase confirmation.

Note*: Only for actuator and hardware required for mounting to valve. Order auxiliary add-ons (e.g., solenoid valve, lockout & PST, limit switch, chemical resistant adder, etc.) separately. If buyer requires assembly of auxiliary add-ons and/or valve, labor will be charged separately.