

Generic Input		Easytork internal use only	
Valve Brand	Marwin	Valve Brand Truncate	MW
Series	CV4700 Full Port	Series Truncate	CV4700
Input: 1 = mm / 2 = in	2		
Safety Factor	25%		



Actuator Design Year

16

Valve Input

Valve Torque		Direct Mount Check		Section Only For Non Direct Mount ("D.M"), Otherwise Leave Blank						Valve Dimension							
				Bracket Check		Extended Shaft Check		Buyer Preference		Valve Info		Valve Flange		Valve Dimension		Valve Stem Shape and Dimension	
Published valve torque	Incl. safety factor	Any obstruction over flange?	1=Yes / 0=No	Possible obstruction for std. Easytork bracket?	Out. dia. of obstruction over flange surface	Are bolts for packing gland close to valve stem height?	If bolts interfere with valve stem, what is inside dia. between bolts?	If w/ bracket: How much valve stem capture?	If known, capturable valve stem height	In ISO (i.e. F05)	Flange to top of valve stem	Stem Shape	Valve stem dimension in in or mm	V	V1	V2	Insert orientation when valve is CLOSED. If Sq 1=diamond / 2=square If DD or B+K 1=in line / 2=not in line
Valve Size	in-lb	in-lb	1=Yes / 0=No	1=Yes / 0=No	in/mm	1=Yes / 0=No	in/mm	in/mm	in/mm	in/mm	in/mm	in/mm	Key	in / mm	in/mm	in/mm	in/mm
1/2"	45	56	No								F04	0.32	1	in	0.350	0.350	1
3/4"	70	88	No								F04	0.32	1	in	0.350	0.350	1
1"	130	163	No								F05	0.40	1	in	0.430	0.430	1
1 1/2"	350	438	No								F07	0.58	1	in	0.550	0.550	1
2"	800	1,000	No								F07	0.58	1	in	0.550	0.550	1
		0															
		0															
		0															
		0															
		0															
		0															
		0															
		0															
		0															
		0															

Notes:



**Disclaimer: Based on information available from valve manufacturer. All dimensions to be verified by customer prior to purchase confirmation.**

Individual Part Order Code\*

(If ordered with the below order codes, Easytork will ship each part as standalone)

2017 List Price

Complete Actuator to Valve

Order Code\*

Valve Size	Required Actuator Range	Individual Part Order Code*				2017 List Price					Complete Actuator to Valve Order Code*
		Actuator	Insert	Extended Shaft	Bracket	Actuator +	Insert +	Extended Shaft +	Bracket or Plate +	= Total Package: Actuator and hardware for mounting to valve	
1/2"	EVA-0309	C-A-1-11-1-111									MW.CV4700.1/2".0309.16
	EVA-0309	C-A-1-11-1-111									MW.CV4700.1/2".0309.16
3/4"	EVA-0309	C-A-1-11-1-111									MW.CV4700.3/4".0309.16
	EVA-0309	C-A-1-11-1-111									MW.CV4700.3/4".0309.16
1"	EVA-0309	C-A-1-11-1-111	D-111-0.430x0.430in								MW.CV4700.1".0309.16
	EVA-0411	C-A-2-11-1-111									MW.CV4700.1".0411.16
1 1/2"	EVA-0514	C-A-3-11-1-111									MW.CV4700.1 1/2".0514.16
	EVA-0717	C-A-4-11-1-111	D-411-0.550x0.550in								MW.CV4700.1 1/2".0717.16
2"	EVA-0717	C-A-4-11-1-111	D-411-0.550x0.550in								MW.CV4700.2".0717.16
	EVA-1022	C-A-5-11-1-111	D-511-0.550x0.550in								MW.CV4700.2".1022.16

Easytork will ship the actuator, insert, extended shaft, and bracket unassembled in one SKU box.

Refer to [Assembly & Labor tab](#) if buyer wants Easytork to assemble items together.

**Disclaimer:** Based on information available from valve manufacturer. All dimensions to be verified by customer prior to purchase confirmation.

**Note\*:** Only for actuator and hardware required for mounting to valve. Order auxiliary add-ons (e.g., solenoid valve, lockout & PST, limit switch, chemical resistant adder, etc.) separately. If buyer requires assembly of auxiliary add-ons and/or valve, labor will be charged separately.