

| Valve Size | Required Actuator Range | Individual Part Order Code* (If ordered with the below order codes, Easytork will ship each part as standalone) | | | | 2017 List Price | | | | | Complete Actuator to Valve Order Code* |
|------------|-------------------------|--|---------------------|----------------|---------|-----------------|----------|------------------|--------------------|---|--|
| | | Actuator | Insert | Extended Shaft | Bracket | Actuator + | Insert + | Extended Shaft + | Bracket or Plate + | = Total Package: Actuator and hardware for mounting to valve | |
| 1/4" | EVA-0309 | C-A-1-11-1-111 | | | | | | | | | SH.11.1/4".0309.16 |
| | EVA-0309 | C-A-1-11-1-111 | | | | | | | | | SH.11.1/4".0309.16 |
| 3/8" | EVA-0309 | C-A-1-11-1-111 | | | | | | | | | SH.11.3/8".0309.16 |
| | EVA-0309 | C-A-1-11-1-111 | | | | | | | | | SH.11.3/8".0309.16 |
| 1/2" | EVA-0309 | C-A-1-11-1-111 | | | | | | | | | SH.11.1/2".0309.16 |
| | EVA-0309 | C-A-1-11-1-111 | | | | | | | | | SH.11.1/2".0309.16 |
| 3/4" | EVA-0309 | C-A-1-11-1-111 | | | | | | | | | SH.11.3/4".0309.16 |
| | EVA-0411 | C-A-2-11-1-111 | D-211-0.350x0.350in | | | | | | | | SH.11.3/4".0411.16 |
| 1" | EVA-0411 | C-A-2-11-1-111 | D-211-0.350x0.350in | | | | | | | | SH.11.1".0411.16 |
| | EVA-0411 | C-A-2-11-1-111 | D-211-0.350x0.350in | | | | | | | | SH.11.1".0411.16 |
| 1 1/4" | EVA-0411 | C-A-2-11-1-111 | | | | | | | | | SH.11.1 1/4".0411.16 |
| | EVA-0514 | C-A-3-11-1-111 | D-311-0.430x0.430in | | | | | | | | SH.11.1 1/4".0514.16 |
| 1 1/2" | EVA-0411 | C-A-2-11-1-111 | | | | | | | | | SH.11.1 1/2".0411.16 |
| | EVA-0514 | C-A-3-11-1-111 | D-311-0.430x0.430in | | | | | | | | SH.11.1 1/2".0514.16 |
| 2" | EVA-0411 | C-A-2-11-1-111 | | | | | | | | | SH.11.2".0411.16 |
| | EVA-0514 | C-A-3-11-1-111 | D-311-0.430x0.430in | | | | | | | | SH.11.2".0514.16 |

Easytork will ship the actuator, insert, extended shaft, and bracket unassembled in one SKU box.

Refer to [Assembly & Labor](#) tab if buyer wants Easytork to assemble items together.

Disclaimer: Based on information available from valve manufacturer. All dimensions to be verified by customer prior to purchase confirmation.

Note*: Only for actuator and hardware required for mounting to valve. Order auxiliary add-ons (e.g., solenoid valve, lockout & PST, limit switch, chemical resistant adder, etc.) separately. If buyer requires assembly of auxiliary add-ons and/or valve, labor will be charged separately.